



MATERIAL HANDLING SYSTEMS

CRANE SPECIFICATIONS & OPERATION MANUAL

MODELS 0.5/4, 1.5/10, 1.7/12, 2.0/15T, 2.6/19T

IOWA MOLD TOOLING CO., INC.

**BOX 189, GARNER, IA 50438-0189
641-923-3711**

MANUAL PART NO: 99903422

Iowa Mold Tooling Co., Inc. is an Oshkosh Corporation Ccompany.

TABLE OF CONTENTS

1.0 CRANE DESCRIPTION	5
MODEL 0.5/4	5
MODEL 1.5/10, 2.0/15T, 2.6/19T	6
MODEL 1.7/12	7
2.0 OPERATING INSTRUCTIONS	8
2.1 START UP	8
2.1.1 STABILIZER SET-UP (IF APPLICABLE)	8
2.2.2 STARTING THE HYDRAULIC SYSTEM	9
2.3 FOLDING / UNFOLDING THE CRANE	9
2.4 SAFE DISTANCES TO ELECTRICAL WIRES	10
2.5 ATTACHING THE LOAD	10
2.6 LOADER REACH & CAPACITY	10
2.6.1 MODEL 0.5/4 CAPACITY CHART	11
2.6.2 MODEL 1.5/10 CAPACITY CHART	11
2.6.3 MODEL 1.7/12 CAPACITY CHART	11
2.6.4 MODEL 2.0/15T CAPACITY CHART	12
2.6.5 MODEL 2.6/19T CAPACITY CHART	12
2.7 CRANE OPERATION	13
2.7.1 OPERATION - MODEL 0.5/4	13
2.7.2 OPERATION - MODELS 1.5/10, 2.0/15T & 2.6/19T	13
2.7.3 OPERATION - MODEL 1.7/12	14
3.0 EXTENSION ACCESSORIES (MODEL 1.7/10 ONLY)	14
4.0 HYDRAULIC SAFETY SYSTEM	15
4.1 MODEL 1.5/10, 2.0/15T, 2.6/19T HYDRAULIC SAFETY SYSTEM	15
4.2 MODEL 1.7/12 HYDRAULIC SAFETY SYSTEM	16
4.3 MODEL 1.5/10 ELECTRO-HYDRAULIC DIAGRAM	17
4.3.2 MODEL 1.5/10 HYDRAULIC DIAGRAM.....	18
4.3.3 MODEL 2.0/15T ELECTRO-HYDRAULIC DIAGRAM	19
4.3.4 MODEL 2.0/15T HYDRAULIC DIAGRAM	20
4.3.5 MODEL 2.6/19T ELECTRO-HYDRAULIC DIAGRAM	21
4.3.6 MODEL 2.6/19T HYDRAULIC DIAGRAM	22
4.3.5 MODEL 1.7/12 PTO HYDRAULIC DIAGRAM	23
4.3.6 MODEL 1.7/12 ELECTRO-HYDRAULIC DIAGRAM	24
5.0 MAINTENANCE	25
5.1 MODEL 0.5/4 - DAILY MAINTENANCE POINTS	25
5.2 MODEL 1.5/10, 2.0/15T, 2.6/19T - DAILY MAINTENANCE POINTS	26
5.3 MODEL 1.7/12 - DAILY MAINTENANCE POINTS	27
6.0 LUBRICATION & OIL CHANGE	28
6.1 MODEL 1.5/10, 2.0/15T, 2.6/19T GREASE ZERK LOCATIONS	28
6.2 MODEL 1.7/12 GREASE ZERK LOCATIONS	28
6.3 CHANGING THE OIL AND OIL FILTER	29
6.3.1 MODEL 1.5/10, 2.0/15T, 2.6/19T - CHANGING THE OIL & OIL FILTER BY THE ELECTRIC POWER PACK.....	29
6.3.2 MODEL 1.5/10, 2.0/15T, 2.6/19T - CHANGING THE OIL & OIL FILTER BY PTO- HYDRAULIC	29

TABLE OF CONTENTS, CONTINUED

6.3.3 MODEL 1.7/12 - CHANGING THE OIL & OIL FILTER	29
6.3.4 HYDRAULIC OIL & GREASE SPECIFICATIONS	30
7.0 BLEEDING AIR FROM CYLINDERS	31
7.1 MODEL 1.5/10, 2.0/15T, 2.6/19T	31
7.2 MODEL 1.7/12	32
7.3 ACCESSORIES (MODELS 1.5/10, 2.0/15T, 2.6/19T ONLY)	32
8.0 CHANGE OF SLEWING AREA	33
8.1 MODEL 1.5/10, 2.0/15T, 2.6/19T CHANGE OF SLEWING AREA	33
8.2 MODEL 1.7/12 MOUNTING, CHANGE OF SLEWING AREA	34
9.0 TECHNICAL DATA	35
9 DIMENSIONAL DRAWINGS & TECHNICAL DATA	35
9.1A MODEL 0.5/4 DIMENSIONAL DRAWINGS	35
9.1B MODEL 0.5/4 TECHNICAL DATA	36
9.2A MODEL 1.5/10 T1 (T2) DIMENSIONAL DRAWINGS	37
9.2B MODEL 1.5/10 T1 M (T2 M) DIMENSIONAL DRAWINGS	38
9.2C MODEL 1.5/10 TECHNICAL DATA	39
9.2D POWER CONSUMPTION / PUMP PERFORMANCE	39
9.3A DIMENSIONAL DRAWINGS - MODEL 1.7/12 K2 SERIES	40
9.3B MODEL 1.7/12 TECHNICAL DATA	41
9.4A: DIMENSIONAL DRAWING, 2.0/15T	42
9.4B: DIMENSIONAL DRAWING, 2.0/15T STATIONARY MOUNT	43
9.4C: 2.0/15T TECHNICAL DATA	44
9.5A: DIMENSIONAL DRAWING, 2.6/19T	45
9.5B: 2.6/19T TECHNICAL DATA	46
10.0 MODEL 1.7/12 TROUBLESHOOTING	47
11.0 REPAIR	49

In addition to the information presented in this manual, read and understand the IMT Crane Operator's Safety Manual before operating or performing any maintenance on your crane.


REVISIONS LIST

DATE	LOCATION	DESCRIPTION OF CHANGE
20030611	11 COVER	REVISED CAPACITY PLACARD TO INCLUDE MANUAL EXTENSION NOTE
20070228		UPDATED OWNERSHIP STATEMENT
20091120		ADDED MODEL 2.0/15T
20100414		ADDED MODEL 2.6/19T
20111129		ECN 11628 - UPDATED STABILIZER VERBIAGE, ELEC. DISTANCES

1.0 CRANE DESCRIPTION


MODEL 0.5/4

1. BASE
2. MAST
3. LOWER BOOM
4. EXTENSION BOOM
5. HINGE PIN
6. CYLINDER BOLT
7. EXTENSION PIN
8. LOWER BOOM CYLINDER
9. ROTATION / SLEWING CRANK
10. HAND PUMP
11. PUMP LEVER
12. HOOK




MODEL 1.5/10, 2.0/15T, 2.6/19T

1. BASE
2. ROTATION / SLEWING CYLINDER
3. MECHANICAL STABILIZER LEG
4. STABILIZER BEAM
5. MAST
6. LOWER BOOM CYLINDER
7. HINGE PIN
8. LOWER BOOM
9. EXTENSION CYLINDER
10. 1st EXTENSION BOOM, 100 MM (1.5/10) or 120 MM (2.0/15T or 2.6/19T)
11. 2nd EXTENSION BOOM, 83 MM (1.5/10) or 100 MM (2.0/15T or 2.6/19T)
12. HOOK
13. CONTROL VALVE BLOCK
14. MOUNTING HARDWARE



MODEL 1.7/12

1. BASE
2. MOUNTING HARDWARE
3. MECHANICAL STABILIZER LEG
4. STABILIZER BEAM
5. ROTATION / SLEWING CYLINDER
6. MAST
7. INNER BOOM
8. HINGE PIN
9. INNER BOOM CYLINDER
10. LOCK FOR BOOM CYLINDER & EXTENSION
11. OUTER / JIB
12. OUTER / JIB CYLINDER
13. OUTER / JIB PIN
14. 1ST EXTENSION BOOM, 100 MM
15. EXTENSION CYLINDER
16. 2ND EXTENSION BOOM, 80 MM
17. HOOK
18. CONTROL VALVE



2.0 OPERATING INSTRUCTIONS

2.1 START UP

Before operating the loader:

- Set vehicle parking brake.
- Check oil levels in the tank and power pack.
- Check hoses for damage, twists, or kinks.
- Check all hooks, slings, and chains, if applicable.
- Check that manual extensions are correctly fastened with lock bolts and split pins, if applicable.
- DO NOT exceed the maximum load on manual extensions, if applicable.

2.1.1 STABILIZER SET-UP (IF APPLICABLE)

CAUTION


NEVER OPERATE THE LOADER IF THE STABILIZERS ARE NOT LOWERED!

For proper operation, the stabilizer legs should be lowered just enough to raise the truck chassis suspension slightly. The truck, including the crane, should be parked on even ground to give a nearly perfect slew of the crane.

If the job is on soft ground, put wooden blocks or steel plates under the stabilizer legs to ensure stability. (On Model 1.5/10, the weight on the stabilizer leg can exceed 1.3 tons.)

To set-up the stabilizer leg, release the stabilizer lock and extend the stabilizer beam completely. Then, re-lock it.

If the loader is equipped with swing-up stabilizer legs, they must be vertically locked.



2.2.2 STARTING THE HYDRAULIC SYSTEM

Start the engine, disengage the clutch, and engage the PTO by pulling the handle located in the truck cab.

2.3 FOLDING / UNFOLDING THE CRANE


After the stabilizer leg has been lowered (if applicable), unfold the boom as shown.

NOTE

NEVER STAND UNDER A CRANE WHEN IT IS BEING UNFOLDED.


NEVER START UNFOLDING DURING A SLEWING MOVEMENT.

UNFOLDING MODEL 0.5/4, 1.5/10, 2.0/15T, 2.6/10T




UNFOLDING MODEL 1.7/12

Forward movement of boom to unlock extensions.



Rear movement of boom to lock extensions.



2.4 SAFE DISTANCES TO ELECTRICAL WIRES

	NORMAL VOLTAGE kV (Phase to Phase)	MINIMUM REQUIRED CLEARANCE Feet (meters)
OPERATION NEAR HIGH VOLTAGE	From 0 to 350 Over 350 or unknown	20 (6.10) 50 (15.24)
OPERATION IN TRANSIT WITH NO LOAD AND BOOM OR MAST LOWERED.	From 0 to 0.75 From 0.75 to 50 From 50 to 345 From 345 to 750 From 750 to 1000	4 (0.22) 6 (0.83) 10 (3.05) 16 (4.87) 20 (8.10)

2.5 ATTACHING THE LOAD

Attach the load and auxiliary equipment securely and carefully to the hook directly or by use of straps or chains.

2.6 LOADER REACH & CAPACITY

Figures for reach and capacity are shown on the capacity charts on the following pages. Your crane is designed for specific loads which are defined on the capacity placard which is mounted near the operator's station and on the crane. Exceeding the limits presented on the capacity placard will create severe safety hazards and will shorten the life of the crane. The operator and other concerned personnel must know the load capacity of the crane and the weight of the load being lifted!

WARNING

NEVER EXCEED THE CRANE'S RATED LOAD CAPACITIES. DOING SO WILL CAUSE STRUCTURAL DAMAGE AND DAMAGE TO WINCHES AND CABLES WHICH CAN LEAD TO SERIOUS INJURIES OR DEATH.


NOTE

LOAD LIMIT INFORMATION ON THE CAPACITY PLACARD IS FORMULATED ON 85% OF TIPPING. "TIPPING" REFERS TO THE CRANE ACTUALLY TIPPING WITH ITS OPPOSITE STABILIZER AND TIRES HAVING BROKEN CONTACT WITH THE SURFACE.


Prior to lifting a load:

1. Determine the weight of the load.
2. Determine the weight of any load handling devices.
3. Add the weight of the load and the weight of the load handling devices. The sum will be the total weight of the load being lifted.
4. Determine the distance from the centerline of crane rotation to the centerline of the load being lifted.
5. Determine the distance from the centerline of crane rotation to the centerline of where the location to which the load is to be moved.
6. The actual distance used should be figured as the larger of items 4 and 5 above.
7. Determine at what angle the crane will be operated (for example 30°, 45°, etc.) by referencing the angle indicator on the lower boom.
8. Make certain that 2-part line is used for any lift which requires 2-part line.


2.6.1 MODEL 0.5/4 CAPACITY CHART




2.6.2 MODEL 1.5/10 CAPACITY CHART




2.6.3 MODEL 1.7/12 CAPACITY CHART



2.6.4 MODEL 2.0/15T CAPACITY CHART




2.6.5 MODEL 2.6/19T CAPACITY CHART



2.7 CRANE OPERATION

2.7.1 OPERATION - MODEL 0.5/4

Crane model 0.5/4 is operated using pumps and cranks. The lifting and lowering functions of the crane are operated using a hand pump with a needle valve, and the crane slew is operated by turning a crank. An optional power unit is available instead of the hand pump for lifting, if ordered with the crane.




2.7.2 OPERATION - MODELS 1.5/10, 2.0/15T & 2.6/19T


These crane models are operated using control valves. Move the control valves gently, especially when working with heavy loads. The working speed of the crane is controlled using the valves. Jerky control valve operation causes the load to swing and move uncontrollably and put unnecessary strain on the crane.

NOTE

ALWAYS OPERATE CONTROL LEVERS GENTLY AND STEADILY.



2.7.3 OPERATION - MODEL 1.7/12



3.0 EXTENSION ACCESSORIES (MODEL 1.7/10 ONLY)


Extra extensions can be supplied for the crane. The extensions are carefully fitted for the crane and must not be shortened or lengthened. Only factory-supplied extensions must be used.

NOTE


THE LOADS ON THE EXTENSIONS MUST NOT EXCEED THE MAXIMUM LOADS INDICATED ON THE CAPACITY CHART.

Do not use tools which were not intended for your type of loader. Do not weld or drill in the bearing structure of the loader. Alterations to the loader construction can void the manufacturer's warranty.

MODEL 1.5/10



MODEL 1.7/12



4.0 HYDRAULIC SAFETY SYSTEM

NOTE: Model 0.5/4 has manual extensions and controls, so this section does not apply to that model.

4.1 MODEL 1.5/10, 2.0/15T, 2.6/19T HYDRAULIC SAFETY SYSTEM

1) Control Valve

Main relief valve

- Safeguard in case of overload.

2) Rotation/Slewing Cylinder

Double port-relief valve

- Safeguard in case of overload.

3) Lower Boom Cylinder

Single-acting load-holding valve

- Safeguard in case of hose failure/ overload
- Keeps the boom in position by relieving pressure on pipes and hoses

4) Stabilizer Cylinder


Piloted check valve

- Safeguard in case of hose failure / overload

5) Extension Cylinder

Double-acting, load-holding valve

- Safeguard in case of hose failure / overload
- Keeps the boom in position by relieving pressure on pipes and hoses



4.2 MODEL 1.7/12 HYDRAULIC SAFETY SYSTEM

1) Inner & Outer Cylinders

Single-acting load-holding valve

- Safeguard in case of hose failure.
- Safeguard in case of overload.
- Keeps the boom in position by relieving pressure on pipes and hoses.

2) Extension Cylinder

Double piloted check valve

- Safeguard in case of hose failure
- Keeps the boom in position by relieving pressure on pipes and hoses

3) Rotation/Slewing Cylinder

Double port-relief valve

- Safeguard in case of overload

4) Control Valve


Main-relief valve

- Safeguard in case of overload


5) Stabilizer Cylinder

Piloted check valve


- Safeguard in case of hose failure




4.3 MODEL 1.5/10 ELECTRO-HYDRAULIC DIAGRAM




4.3.2 MODEL 1.5/10 HYDRAULIC
DIAGRAM




4.3.3 MODEL 2.0/15T ELECTRO-HYDRAULIC DIAGRAM




4.3.4 MODEL 2.0/15T HYDRAULIC
DIAGRAM




4.3.5 MODEL 2.6/19T ELECTRO-HYDRAULIC DIAGRAM




4.3.6 MODEL 2.6/19T HYDRAULIC DIAGRAM



4.3.5 MODEL 1.7/12 PTO HYDRAULIC DIAGRAM



4.3.6 MODEL 1.7/12 ELECTRO-HYDRAULIC DIAGRAM



5.0 MAINTENANCE

5.1 MODEL 0.5/4 - DAILY MAINTENANCE POINTS


● Check pins, splits, etc.

■ Tighten bolts if necessary.

▲ Lubricate with oil can.

- Replenish the tank (base) if needed.
- Check hoses for damage and leaks.

Fill
with
oil.




5.2 MODEL 1.5/10, 2.0/15T, 2.6/19T - DAILY MAINTENANCE POINTS

- Check the oil level in the base.
- Periodically check hoses and pipes for damage and leaks.

● Check pins, splits, etc.

■ Tighten bolts if necessary.




5.3 MODEL 1.7/12 - DAILY MAINTENANCE POINTS

- Check the oil level in the base.
- Periodically check hoses and pipes for damage and leaks.

● Check pins, splits, etc.

■ Tighten bolts if necessary.




6.0 LUBRICATION & OIL CHANGE

The crane should be lubricated thoroughly at the same intervals as the truck. However, in case of intensive use, it should be lubricated weekly. If the crane is used continuously, it should be lubricated daily.

NOTE:


Check the oil level in the base periodically.

6.1 MODEL 1.5/10, 2.0/15T, 2.6/19T GREASE ZERK LOCATIONS



KEY - GREASE ZERK CHARTS	
	Fill with oil at these locations.
	Grease zerk locations.
	Apply grease with a spatula.
	Apply grease with a brush.

6.2 MODEL 1.7/12 GREASE ZERK LOCATIONS



NOTES:


- Change oil and oil filter on an annual basis.
- Keep water and impurities from the oil tank.
- If necessary, refill the oil tank after bleeding air from the system.
- Do not mix different brands of oil.

6.3 CHANGING THE OIL AND OIL FILTER

6.3.1 MODEL 1.5/10, 2.0/15T, 2.6/19T - CHANGING THE OIL & OIL FILTER BY THE ELECTRIC POWER PACK


1. Fold the crane completely.
2. Remove the air filter (1), and empty the oil tank.
3. Dismantle the nut (3) in the end plate of the oil tank, remove the tank, and change the oil filter (2) if necessary.
4. Mount the tank and fill it with oil.

NOTE: Fill the tank with 2.11 gallons (8 l) of oil, even if the base is not used as a tank.




6.3.2 MODEL 1.5/10, 2.0/15T, 2.6/19T - CHANGING THE OIL & OIL FILTER BY PTO-HYDRAULIC

1. Remove the air filter (1) and the drain plug. Empty the oil tank.
2. Change the oil filter (2).
3. Mount the drain plug. Fill the tank with oil.
4. Mount the air filter (1).



6.3.3 MODEL 1.7/12 - CHANGING THE OIL & OIL FILTER

1. Unscrew the oil filter and drain plug. Empty the oil tank.
2. Unscrew and replace the oil filter.
3. Tightly screw the drain plug. Refill oil to the top mark of the dipstick.
4. Replenish the tank after bleeding air from the cylinders, if necessary.



6.3.4 HYDRAULIC OIL & GREASE SPECIFICATIONS

Choose hydraulic oils and greases using the tables below as guides. If the loader will be working below 32° F (0° C), select an oil designed for low temperatures, which has a higher viscosity index. Oil types not specified on the charts may be used if they correspond to the quality and specifications indicated.

In the winter, 1% isopropyl alcohol may be added to the oil to avoid condensed water problems.

During extreme temperatures, -40° F / + 167 °F (-40° C / +75° C), select hydraulic oil such as Esso Univis J26 or another comparable brand.

Grease telescopic jibs with Esso ESL 454. Apply grease where the telescopic jibs contact the slide blocks.

APPLICATION POINT	LUBRICATION PRODUCT	APPLICATION MEANS	INTERVAL
Pinion and Drive Gear Rotation Brake Winch Brake Winch Sheave Turntable Bearing Cylinder Pins Boom Hinge Pins Boom Rollers	Shell Alvania 2EP OR Shell Retinax "A" OR Mobilith AW2 OR Equivalent	Hand Grease Gun OR Pneumatic Pressure Gun	Weekly
Rotation Worm Gear	Molub-Alloy 936 or Equiv.	Brush On	Weekly
PTO Transmission Winch Sump	Mobilube HD 80W90	Fill to Check Plug	Monthly

HYDRAULIC OIL SPECIFICATIONS AND APPLICATION POINTS

AMBIENT TEMPERATURE RANGE	0 - 90°	BELOW 0°	ABOVE 90°
Minimum Pour Point, °F	-40°	-40°	-10°
Maximum Viscosity, SSU @ 0°F	5000	1500	---
Minimum Viscosity, SSU @ 100°F	140-195	80-90	200-335
Minimum Viscosity, SSU @ 210°F	48	39	49
Minimum Viscosity Index	139	139	95
ISO VG Grade	32	15	46
Mobil Oils (Reference)	DTE 13M	DTE 11M	DTE 25


LUBRICANT SPECIFICATIONS






7.0 BLEEDING AIR FROM CYLINDERS

7.1 MODEL 1.5/10, 2.0/15T, 2.6/19T

If air has entered the hydraulic system, bleed the air from the cylinders by:


- 1) Fold the crane completely. Fill the oil tank with 2.11 gallons (8 l) of oil.
- 2) Follow the steps in the diagram below to bleed the air from the cylinders.
- 3) Refill the oil tank after bleeding the cylinders.



7.2 MODEL 1.7/12**Rotation/Slewing
Cylinder****Inner Boom Cylinder****Outer/Jib Cylinder****Extension
cylinder****Outrigger cylinder****7.3 ACCESSORIES (MODELS 1.5/10,
2.0/15T, 2.6/19T ONLY)****MANUAL EXTENSIONS**

An extra jib extension can be supplied for the loader. The manual extension is adapted especially for the particular type of loader. It should not be shortened or lengthened.


Use only factory original manual extensions.



8.0 CHANGE OF SLEWING AREA


8.1 MODEL 1.5/10, 2.0/15T, 2.6/19T CHANGE OF SLEWING AREA

- 1) Position the crane so that the slew to both sides is exactly the same (neutral position).
- 2) Remove oil from the base using the drain plug (5).
- 3) Remove the slewing cylinder (1).
- 4) Pull out the slide block (4) using the M8 threaded hole.
- 5) Pull out the rack (3).
- 6) Manually turn the loader column to the required "C" (Figure 2).
- 7) Place the rack (3) in the slewing house. The distance between the outer part of the rack (3) and the end plate must be approximately $2.8'' \pm .3''$ (71.5 mm \pm 8 mm), depending on the mutual mesh of the teeth.
- 8) Place the slide block (4) behind the rack (3). Remount the slewing cylinder (1).
- 9) Lubricate the bolts (2) with Locktite Normal or Locktite No. 242. Screw the bolts back in.
- 10) Replace the drain plug (5). Replace oil if needed.



8.2 MODEL 1.7/12 MOUNTING, CHANGE OF SLEWING AREA

- 1) CRANE & BASE DISASSEMBLY
 - a. Empty oil from base using the drain plug (7).
 - b. Remove the 4 bolts (1) and the slewing cylinder (2).
 - c. Pull out the slide block (3) to the M8 threaded hole.
 - d. Pull out the rack (4).
 - e. Lift the loader out of the base.




2) CHANGE OF SLEWING AREA & CRANE ASSEMBLY

The slew area of the crane (365°) appears as shown in Figure 1. "C" indicates the center of the slewing area.

- a. When changing the slewing area, follow steps a - d in Section 8.2, Loader Disassembly.
- b. Turn the crane manually to the "C" desired.
- c. Place the rack (4) in the slew housing. The distance from the outer part of the end plate (5) to the rack (4) must be 1.9" (48.5 mm) \pm .31" (8 mm), depending on the mutual mesh of the teeth.
- d. Place the slide block (3) behind the rack (4), then mount the slewing cylinder (2) and the bolts (1).
- e. Screw the drain plug (7) tight and refill oil at the air filter (6).

9.0 TECHNICAL DATA


9.1A MODEL 0.5/4 DIMENSIONAL DRAWINGS




9.1B MODEL 0.5/4 TECHNICAL DATA

LOAD MOMENT	0.5 TM
LIFTING CAPACITY AT:	4'-11" (1.5 m) 948 lb (430 kg) 6'- 7" (2.0 m) 551lb (250 kg)
MANUAL EXTENSIONS	1
MAX. LIFTING HEIGHT ABOVE BASE	122" (3100 mm)
MAX. LOWERING BELOW BASE	35.4" (900 mm)
HEIGHT ABOVE PLATFORM IN PARKED POSITION	54.3" (1380 mm)
POWER SOURCE	HYDRAULIC HAND PUMP (OPTIONAL ELECTRIC POWER PACK FOR LIFT)
SLEWING SYSTEM	WORM GEAR IN OIL BATH
SLEWING ANGLE	> 360°
WEIGHT	137 lb (62 kg)

9.2A MODEL 1.5/10 T1 (T2) DIMENSIONAL DRAWINGS



9.2B MODEL 1.5/10 T1 M (T2 M) DIMENSIONAL DRAWINGS




9.2C MODEL 1.5/10 TECHNICAL DATA

	T1	T2	T1 M	T2 M
LOAD MOMENT	1.5 tm	1.5 tm	1.5 tm	1.5 tm
HYDRAULIC REACH	6'-11" (2.1 m)	9'-8" (2.95 m)	6'-11" (2.1 m)	9'-8" (2.95 m)
SLEWING TORQUE	1013 ft-lb (140 kgm)	1013 ft-lb (140 kgm)	1013 ft-lb (140 kgm)	1013 ft-lb (140 kgm)
HEIGHT ABOVE CHASSIS WHEN FOLDED	61.6" (1565 mm)	61.6" (1565 mm)	59.6" (1515 mm)	59.6" (1515 mm)
WIDTH WHEN FOLDED	20.5" (520 mm)	20.5" (520 mm)	20.5" (520 mm)	20.5" (520 mm)
STABILIZER SPREAD, EXTENSION	13.8" (350 mm)	13.8" (350 mm)	--	--
WEIGHT, LOADER INCL. STABILIZER LEG & POWER PACK	407.9 lb (185 kg)	440.9 lb (200 kg)	--	--
WEIGHT, LOADER EXCL. STABILIZER LEG & POWER PACK	--	--	352.7 lb (160 kg)	385.8 lb (175 kg)
OIL IN BASE	17.6 lb (8 kg)	17.6 lb (8 kg)	17.6 lb (8 kg)	17.6 lb (8 kg)
OIL IN CYLINDERS & HOSES	8.8 lb (4 kg)	8.8 lb (4 kg)	8.8 lb (4 kg)	8.8 lb (4 kg)

9.2D POWER CONSUMPTION / PUMP PERFORMANCE

	ALL MODELS
WORKING PRESSURE	2248 psi (15.5 MPa)
PUMP PERFORMANCE	1.06-2.11 gpm (4 - 8 l/min)
MAX. POWER CONSUMPTION	
12 volt:	155 Amp
24 volt:	80 Amp
BATTERY CAPACITY	
12 volt:	120 Ah
24 volt:	80 Ah
OIL CAPACITY IN BASE	2.11 gal (8 l)


9.3A DIMENSIONAL DRAWINGS -
MODEL 1.7/12 K2 SERIES




9.3B MODEL 1.7/12 TECHNICAL DATA

LOAD MOMENT	2.0 tm
LIFTING CAPACITY AT:	
5'-3" (1.60 m)	2756 lb (1250 kg)
7'-10" (2.40 m)	1819 lb (825 kg)
11'-2" (3.40 m)	1224 lb (555 kg)
14'-5" (4.40 m)	762 lb (350 kg)
MAX. HYDRAULIC REACH	14'-5" (4.40 m)
SLEWING TORQUE	1374 ft-lb (190 kgm)
SLEWING ANGLE	365°
RECOMMENDED PUMP PERFORMANCE AT 18.5 MPa	1.6 - 2.11 gal (6 - 8 l)
OIL CAPACITY	1.72 gal (6.5 l)
HEIGHT ABOVE CHASSIS	65.2" (1655 mm)
HEIGHT ABOVE PLATFORM	58.3" (1480 mm)
BREADTH ABOVE BASE	63.0" (1600 mm)
LENGTH ABOVE BASE	15.4" (390 mm)
MOUNTING BOLTS	4 M16 X 350
WEIGHT:	
COMPLETE W/PTO	650 lb (295 kg)
COMPLETE W/ ELECTROHYDRAULICS	662 lb (300 kg)
OPERATING PRESSURE:	
MAIN-RELIEF VALVE	2611 psi (18.0 MPa)
SLEWING CYLINDER	1798 psi (12.4 MPa)
BOOM/JIB CYLINDER	2756 psi (19.0 MPa)
POWER CONSUMPTION	
MAX	12 V - 200 Amp 24 V - 10 Amp

9.4A: DIMENSIONAL DRAWING, 2.0/15T



9.4B: DIMENSIONAL DRAWING, 2.0/15T STATIONARY MOUNT



9.4C: 2.0/15T TECHNICAL DATA**2.0/15T**

Crane Rating*	14,465 ft-lb (2.0 tm)
Maximum Horizontal Reach	10' 6" (3.2 m)
Maximum Vertical Reach	15' 9" (4.8 m)
Maximum Capacity	3680 lb (1670 kg)
Max Cap @ Max Reach	1325 lb (600 kg)
Crane Weight, incl. stabilizer and power pack	530 lb (240 kg)
Crane Weight, excluding power pack	
Center of Gravity - Stored	
Vertical	16" (405 mm)
Horizontal (C/L RotTo Bridge)	4" (100 mm)
Stabilizer Pad Diameter	6" (160 mm)
Crane Storage Height	5' 6" (1680 mm)
Mounting Space	1' 10" (560 mm)
Rotational Torque	1375 ft lb (190 kg-m)
Rotation	365 degrees
Optimum Pump Performance	1.6 - 2.1 gpm (6-8 L/min)
System Pressure	2610 psi (180 bar)
Oil Capacity in Base	1.7 gal (6.5 L)
Stabilizers	
Extension	2'-0" (610 mm)
Weight	440 lb (200 kg)

2-HYDRAULIC**2-HYDRAULIC STATIONARY-MOUNT**

14,465 ft-lb (2.0 tm)
10' 6" (3.2 m)
15' 9" (4.8 m)
3680 lb (1670 kg)
1325 lb (600 kg)
660 lb (300 kg)
6" (160 mm)
5' 6" (1670 mm)
1' 10" (560 mm)
1375 ft lb (190 kg-m)
365 degrees
1.6 - 2.1 gpm (6-8 L/min)
2610 psi (180 bar)
1.7 gal (6.5 L)
—
--

PRESSURE SETTINGS

Use a pressure gauge when setting pressures. Check pressure with annual inspection and after all major repairs.

WORKING PRESURE ON PORT-RELIEF VALVE

Main relief valve	2610 psi (180 bar)	2610 psi (180 bar)
Rotation (slewing) system	1815 psi (125 bar)	1815 psi (125 bar)

OPENING PRESURE ON LOAD-HOLDING VALVES

Boom cylinder	2755 psi (190 bar)	2755 psi (190 bar)
---------------	--------------------	--------------------

PRESURE SETTINGS


90% load	2320 psi (160 bar)	2320 psi (160 bar)
100% load	2610 psi (180 bar)	2610 psi (180 bar)

PRESSURE SETTINGS FOR LOAD-MOMENT LIMITATION

Set the working pressure of the load-moment limitation to 145 psi (10 bar) less than the opening pressure of the load-holding valves of the boom cylinder. Thus, the setting is 2610 psi (180 bar).

* Crane rating (ft-lb) is the rated load (lb) multiplied by the respective distance (ft) from centerline of rotation with all extensions retracted and the inner and outer booms in a horizontal position, per ANSI B30.22.

9.5A: DIMENSIONAL DRAWING, 2.6/19T



9.5B: 2.6/19T TECHNICAL DATA**2.6/19T****2-HYDRAULIC**

Crane Rating*	18,806 ft-lb (2.6 tm)
Maximum Horizontal Reach	11' 6" (3.5 m)
Maximum Vertical Reach	16' 1" (4.9 m)
Maximum Capacity	3880 lb (1760 kg)
Max Cap @ Max Reach	1610 lb (730 kg)
Crane Weight	605 lb (275 kg)
Center of Gravity - Stored	
Vertical	15" (380 mm)
Horizontal (C/L RotTo Bridge)	12" (310 mm)
Stabilizer Pad Diameter	5.5" (140 mm)
Crane Storage Height	5' 0" (1520 mm)
Mounting Space	1' 7" (475 mm)
Rotational Torque	2460 ft lb (340 kg-m)
Rotation	360 degrees
Optimum Pump Performance	3.2 gpm (12 L/min)
System Pressure	2683 psi (185 bar)
Oil Capacity in Base	2.8 gal (10.5 L)
Stabilizers	
Extension	2'-10" (875 mm)
Weight	62 lb (28 kg)

PRESSURE SETTINGS (Continue from here)

Use a pressure gauge when setting pressures. Check pressure with annual inspection and after all major repairs.

WORKING PRESURE ON MAIN-RELIEF VALVES AND PORT-RELIEF VALVE

Main relief valve	A & B-ports	2683 psi (185 bar)
Stabilizer legs, grab, rotator	Up & Down	2540 psi (175 bar)
Extension cylinders	Extend (B-port)	1815 psi (125 bar)
	Retract (A-port)	P
Boom cylinder	Down (B-port)	1815 psi (125 bar)
	Up (A-port)	2683 psi (185 bar)
Rotation system	Right (B-port)	1450 psi (100 bar)
	Left (A-port)	1450 psi (100 bar)

OPENING PRESURE ON LOAD-HOLDING VALVES

Boom cylinder	2830 psi (195 bar)
Extension cylinders	3625 psi (250 bar)

PRESURE SETTINGS FOR LOAD-MOMENT LIMITATION + 100% load 2685 psi (185 bar)

PRESURE SETTINGS FOR LOAD-MOMENT LIMITATION + 90% load 2395 psi (165 bar)

* Crane rating (ft-lb) is the rated load (lb) multiplied by the respective distance (ft) from centerline of rotation with all extensions retracted and the inner and outer booms in a horizontal position, per ANSI B30.22.

10.0 MODEL 1.7/12 TROUBLESHOOTING

SYSTEM	ISSUE	CAUSE	REMEDY
ROTATION/ SLEWING	The slewing torque is too slow; the loader slews too slowly.	Port-Relief Valve Seals	Defective pressure setting. Check inside of cylinder.
	The boom continues to slew after the operator has released the lever.	Port-Relief Valve Seals	Defective pressure setting.
	The slewing speed changes when other functions are operated.	Contact your dealer or IMT.	
	Too much system backlash.	Contact your dealer or IMT.	
EXTENSION CYLINDER	With jibs pointing upward, the extension ram is pressed inward under load.	Leakage at pipes/hoses. Seals. Piloted check valve.	Defective ball seat. Stuck piston.
	With jibs pointing downward, the extension ram is extended under load.	Leakage at pipes/hoses. Seals. Piloted check valve.	Defective ball seat. Stuck piston.
STABILIZER LEGS	Pressed inward under load.	Leakage at pipes/hoses. Seals. Piloted check valve.	Defective ball seat. Stuck piston.
	Sink during road travel.	Seals. Leakage at pipes/hoses. Piloted check valve.	Defective o-ring on piston.
INNER BOOM & OUTER/JIB CYLINDER	The crane cannot lift enough- raises slowly.	Main relief valve - pump Seals.	
	The arm sinks.	Overload Defective load-holding valve Seals.	
	The arm jerks.	Air in the cylinder. Wrong pilot ration in load- holding valve.	Bleed cylinders.

SYSTEM	ISSUE	CAUSE	REMEDY
PTO (Crane does not work properly - is slow or irregular at several functions - does not lift enough.)	Transmission pump rotates. Transmission pump doesn't rotate.	Wrong pump type-contact dealer or IMT. Test w/test unit. PTO is not engaged. Key in drive shaft is broken.	
ELECTRO-HYDRAULICS (Crane does not work properly - is slow or irregular at several functions - does not lift enough.)	Electric motor pump rotates. Electric motor pump rotates too slowly or does not rotate.	Oil level too low. Oil too heavy. Air filter clogged up. Air in hydraulic system. Relief valve setting too low. Overload. Defect between motor & pump. Defective pump. No ground connection. Supply voltage incorrect. Defective wire connection. Defective start relay. Defective motor. Oil in the motor.	
BOTH PTO & ELECTRO-HYDRAULICS SYSTEMS	Tank suction filter. Tank air filter. Tank oil. Suction line. Main-relief valve	Dirty Iced over, clogged up. Iced over, clogged up. Too low oil level. Too heavy oil. Too long- diameter is too small. Leaking (sucks in air). Damaged or flattened. Pressure setting too low. If pressure cannot be re-set:	Reset pressure at dealer or IMT. Defective main relief valve.

11.0 REPAIR

If your crane needs repair, always use an authorized IMT dealer.

When ordering spare parts, know the:

Crane Model i.e. Model 1.7/12

Serial Number i.e. 421397

Reference number of the spare part required.

If you do not have a spare parts manual, contact your dealer to order one.

IOWA MOLD TOOLING CO., INC.

BOX 189, GARNER, IA 50438-0189

641-923-3711

TECHNICAL SUPPORT FAX: 641-923-2424